

WRAP 2 Indoor



Quick Start Guide

Thank you for purchasing a Yawarra WRAP 2 Indoor.

Your package should contain:

- WRAP 2 board, indoor case, SMA punchout blanking plugs

Optional Extras

- Compact Flash card
- miniPCI card(s)
- Pigtail(s)
- Antenna(s)
- Power supply

Please read the following instructions to begin using your WRAP.

WRAP 2 Indoor – Quick Start Guide

Things you will need

Tools

- Anti-static wrist strap
- Phillips head screwdriver
- Nut driver or small adjustable spanner (optional)
- Compact Flash card reader (optional)
- Null modem cable (optional)



Materials

If you don't have them already, you'll need:

- Compact Flash Card
- miniPCI cards e.g. wireless adapter, VPN accelerator (optional)
- Pigtail(s) and antenna(s)
- Power supply
- Operating system image for the WRAP

Instructions

Safety Note

The WRAP board, like all electronic equipment, is sensitive to damage from static discharge. To avoid damage caused by static discharge, it is strongly recommended that you use an anti-static wrist strap when handling the board.

Step 1 Remove the case

To install the Compact Flash (CF) and/or miniPCI cards into the WRAP, you will need to remove the board from the case.

1. Disconnect power and all cables.
Note: The CF socket on this machine is not hot-swappable.
2. Remove the four screws from the face plate on the rear of the case (the end with the ethernet and serial ports).
3. Holding the board by the serial port, carefully slide the board out from the case.
Note: You do not need to remove the face plate from the board to set up your WRAP box. To remove the face plate from the board, remove the serial port screws.

Step 2 Configure and install a Compact Flash card

To use your WRAP, you will need to have a CF card with a suitable operating system installed in the CF socket on the WRAP board.

WRAP 2 Indoor – Quick Start Guide

If your CF card does not already have an operating system installed, you can either mount the CF card in another machine (e.g. via a flash card reader or a CF to IDE adapter) and copy a boot image onto it, or pxe boot the WRAP. The WRAP supports many operating systems including BSD, Linux and a number of proprietary operating systems.

Installation

Insert the CF card into the socket on the underside of the board, label up. Ensure the CF card is fully engaged in the socket.

Removal

To remove the CF card from the WRAP board, grasp the CF card firmly between thumb and index finger and pull straight out, taking care not to lift or twist the card as this may damage the connector pins.

Step 3 Install the miniPCI card(s) (optional)

Insert your miniPCI card into the miniPCI slot at an angle of about 45° to the board. Ensure that the card is firmly seated in the slot and then lay it onto the board, pressing down until the locking tabs on either side of the card click into place.

Step 4 Install the pigtail(s) (optional)

Remove the rubber blanking plug from the punchout in the face plate and insert the SMA pigtail. Screw the pigtail retaining nut and washer onto the pigtail to secure it to the case.

Attach the u.fl end of the pigtail to the connector on the wireless card. If your wireless adapter is on the underside of the board, feed the pigtail cable through one of the board mounting holes before attaching it to the card.

Step 5 Reinstall the board into the case

Before you can begin using your WRAP, you will need to reinstall the board into the case.

1. Slide the board, with face plate attached, back into the case, ensuring that the edges of the board are inserted into the slots in the sides of the case.
2. Insert the face plate screws and tighten.

EMC Compliance

Please note that in order to comply with ACA emissions regulations, the WRAP board must be housed in a suitable metal enclosure.

Step 6 Attach the antenna(s) (optional)

Screw the antenna onto the pigtail and position as required.

WRAP 2 Indoor – Quick Start Guide

Step 7 Connect to the serial console (optional)

If you want to configure your operating system via the console, you will need to connect to the serial port via a null modem cable.

Your terminal emulator should be set to 38400 baud, 8 bits, no parity, 1 stop bit, no flow control.

Step 8 Apply power

Plug the power supply into the DC jack on the WRAP. The WRAP 2 Indoor runs on 7-18V DC, and uses about 5W at 12V (excluding miniPCI cards). You'll need a power supply with a 2.1mm internal, 5.5mm external, centre positive plug.

The WRAP will go through its boot up cycle, which you can watch if you are connected to the serial console. The behaviour of the three LEDs on the WRAP board is as follows:

- during memory check all LEDs on
- during O/S start up left-hand LED on
- after boot up operating system dependent

Your WRAP is ready to use!

More information

For more detailed instructions on using your WRAP, please visit our website at www.yawarra.com.au and download the manufacturer's user guide.

Contact us

Please feel free to contact us if you have any queries regarding your WRAP.

Yawarra Information Appliances Pty Ltd

ABN 56 508 561 638 ACN 111 823 682

Website www.yawarra.com.au

Email enquiries@yawarra.com.au

Phone 1300 859 799

Fax (03) 9800-2279

Mail PO Box 606, Boronia VIC 3155, Australia